

# HGCAL DB - May 25<sup>th</sup>

Ali Al Kadhim



# Upgrade & HGCal


- Phase-2 upgrade of the CMS HGCal will encompass tens of thousands of new sensors.
  - HL-LHC: high luminosity/pileup, radiation levels, ionizing energies.
- Extensive radiation campaigns have been conducted by CMS to determine suitable material and decide sensor layout parameters for operation in HL-LHC environment.
- Many institutions, such as FSU, routinely runs tests on these sensors to determine if they pass these requirements.
  - Achieving HL-LHC will require collaboration between institutions/users on sensors and their results -> Sensor results must be stored in a central database.

# Module Components

- HGICAL requires  $\approx 27,000$  Si detector modules:
  - CE-E module (electromagnetic) or a CE-H module (hadronic).

- At FSU, we only test sensors.

- When assembling these modules, users must have easy access to sensor info/results from a unified DB.



CE-E Si module

(PCB)

Si 8'' sensor


For electrical insulation from base plate

For placement onto cassettes

# Wafer/sensor layout

- At FSU, we run IV and CV tests on Si sensors (SQC).
- We also do PQC, but its test procedures are currently being developed.

$d_{\text{act}}$ ( $\mu\text{m}$ )	Full-size channels
120	432 (HD)
200	192 (LD)
300	192 (LD)




# Spreadsheets to Database

- Summary results of Si sensor analyses have been entered manually in spreadsheets (which grew organically), such as:
  - This is very **error-prone** and **time-consuming**!
  - With this it is also not possible to easily query sensor results/sensor attributes.
  - Doesn't capture **one**  $\Leftrightarrow$  **many** relationships.

- We constructed a relational (SQL) database that stores and updates sensor attributes, summary results, history, location, etc.

- Code: [https://github.com/AliAlkadhim/FSU\\_HGCAL\\_DB](https://github.com/AliAlkadhim/FSU_HGCAL_DB)
  - The power really comes in when our code is combined with HGC\_Sensor\_IVCV\_Analysis, at [https://gitlab.cern.ch/CLICdp/HGCAL/lcd\\_hgcal\\_analysisworkflows](https://gitlab.cern.ch/CLICdp/HGCAL/lcd_hgcal_analysisworkflows)

								HPK full probe card					
Sensor ID	Scratch pad ID	Thickness	P-stop	Oxide type	Flat band volt. (V)	P-stop conc.	Proc.	I_tot 600V < 100uA	I_tot 800V < 2.5 * I_tot 600V	1) Ncell with 1600 > 100nA	2) Ncell with 1600 > 2.5 * 1600 & 1600 > 10nA threshold    1600 > 25nA & 1600 < 10nA	3) More than 8 bad cells: requirem. 1) and 2)	4) More than two neighbour cells bad: requirem. 1) and 2)
N4791_1	100088	300	com	A	-5	STD	FZ	Passed	Failed	1	0	Passed	Passed
N4791_2	100089	300	com	A	-5	STD	FZ	Passed	Passed	0	0	Passed	Passed
N4791_3	100090	300	com	A	-5	STD	FZ	Passed	Passed	0	0	Passed	Passed



Our ERD

# Driving Principles, and How We Achieve Them

In order to exploit the data from results, avoid errors, and avoid wasting time, the database was built to have the following capabilities:

- **Reconstruction:** The DB is able to quickly reconstruct all data that is previously taken (stored in spreadsheets) into a query-able DB.
  - `fsudb createdb --tablenames [select from options: Full_Sensor, HPK_structures, MOS_GCD, PQC, strip_sensors_logistics, HGC_CERN_Sensor_IV_Summary, etc.]`
- **Modularity:** Each time IV/CV analysis is run, the summary results + extra attributes are saved as a separate csv file, such that it can be reconstructed into a DB (with different tables) later.
- **Fast Queries:** we have a full SQL DB (with mysql) as well as an sqlite replica: the sqlite replica enables fast queries from terminal or python, as well as the use of the sqlitebrowser GUI.

# Automated DB Updating

- **Automation:** our code supports *completely automated updating of the DB*.
  - Users can update the DB automatically if they wish to save the results from an IV/CV analysis.
  - **AnalyseMeasurement\_IV <N\_threads> <sensor\_ID>**

- **Previously:** We manually update the spreadsheets by reading the resulting files/graphs.



$I_{tot\_600V} < 100\mu A$	$I_{tot\_800V} < 2.5^*$ $I_{tot\_600V}$	1) Ncell with 1600 > 100nA	2) Ncell with 1800 > 2.5 * 1600 & 1600 > 10nA threshold    1800 > 25nA & 1600 < 10nA	3) More than 8 bad cells: requirem. 1) and 2)	4) More than two neighbour cells bad: requirem. 1) and 2)
Passed	Failed	1	0	Passed	Passed

- **Now:** `fsudb updateDB IV`
  - **With this, the DB is updated with the latest test results automatically!**
- Should we use similar idea, but with the xml schema template and dbloader?
- Similar automated updating should also be possible for PQC.

# Sensor Tables Mapping to Global DB

- Let's work directly with each other (CERN, UCSB, FSU, etc.) and integrate our results/databases into one universal DB!
  - Preservation, access to each other's results, method unification, module assembly, etc.
- Tables, geometries, etc. have been defined in tables (Florian).
- Development DCA:

<https://cmsdcadev.cern.ch>

(GUI Doesn't work)

- We have instructions on copying data to the DB with XML template, but how can we see what int2r and cmsr DBs look like?
  - Potentially most tables should be changed.

Sensor ID	Scratch pad ID	Thickness	P-Stop	Oxide type	Flat band volt. (V)	P-Stop conc.	Proc.	HPK full probe card					
								I <sub>tot</sub> 600V < 100uA	I <sub>tot</sub> 800V < 2.5* I <sub>tot</sub> 600V	1) Ncell with I600 > 100nA	2) Ncell with I800 > 2.5 * I600 & I600 > 10nA threshold    I800 > 25nA & I600 < 10nA	3) More than 8 bad cells: requirem. 1) and 2)	4) More than two neighbour cells bad: requirem. 1) and 2)
N4791_1	100088	300	com	A	-5	STD	FZ	Passed	Failed	1	0	Passed	Passed
N4791_2	100089	300	com	A	-5	STD	FZ	Passed	Passed	0	0	Passed	Passed
N4791_3	100090	300	com	A	-5	STD	FZ	Passed	Passed	0	0	Passed	Passed

Extra fields we need to store




# DCA Naming Scheme

- In Production DCA

([https://cmsdca.cern.ch/hgc\\_cmsr/construct/parts/](https://cmsdca.cern.ch/hgc_cmsr/construct/parts/)),  
{Serial Number, Barcode} → ID.

ID	1807
KindOfPart	HPK Six Inch 128 Cell Silicon Sensor
Manufacturer	Hamamatsu-HPK
Serial number	<b>HPK_6in_128_0003</b>
Name label	None
Barcode	None

- Barcode: Something that was used when sensors are shipped on coin stacks – not relevant/used anymore!
- We get a column of sensor ID & Scratchpad ID from HPK; we need to store both in DB!
- **Sensor ID**: once it's diced from wafer, it's no longer on sensor.
- So, if we have a diced sensor, there is no identifying feature on it other than the **scratchpad ID**.



# “Serial Number” & “Barcode” Naming Scheme

- Production DB:
    - HPK-AA-BBB-SensorID
    - E.g: Serial Number: HPk-8in-198-**N4791\_1**
    - This naming scheme is fine with us!
  - Development DB:
    - HGC\_YYY\_um\_YY\_Type\_Si\_Component ?
    - E.g: HGC\_120um\_HD\_Full\_Si\_Sensor
  - Instead of Barcode (replace this name!), we *need* to store **Scratchpad ID**.
  - E.g. **100088**  $\Leftrightarrow$  HGC-8in-198-**N4791\_1**.
- YYY: {120, 200, 300} (thickness)
  - ZZ: {HD, LD} (density)
  - Type: : {Full, Top, Bottom, Left, Right, Five, Three} (Geometries)
  - Component: {PCB, Sensor, Kapton, Baseplate}
  - AA: {6 in, 8 in}
  - BBB: {198, 444} (No. Cells)



# DCA GUI Parent/Child

- Production Detector Construction Application (DCA: [https://cmsdca.cern.ch/hgc\\_cmsr/construct/parts/](https://cmsdca.cern.ch/hgc_cmsr/construct/parts/)) GUI

Parent							
ID	KindOfPart	Location	Manufacturer	Serial number	Name	Latest status	Record insertion time
2267	HGC Six Inch Silicon Module	SiDet	None	UCSB_HGC_TST_MOD_8		None	Dec. 11, 2017, 8:45 p.m.

Children							
ID	KindOfPart	Location	Manufacturer	Serial number	Name	Latest status	Record insertion time
2780	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-1		None	March 25, 2018, 10:20 p.m.
2781	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-2		None	March 25, 2018, 10:20 p.m.
2782	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-3		None	March 25, 2018, 10:20 p.m.
2783	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-4		None	March 25, 2018, 10:20 p.m.
2784	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-5		None	March 25, 2018, 10:20 p.m.



# DCA GUI Parent/Child

- Production Detector Construction Application (DCA: [https://cmsdca.cern.ch/hgc\\_cmsr/construct/parts/](https://cmsdca.cern.ch/hgc_cmsr/construct/parts/)) GUI

Parent							
ID	KindOfPart	Location	Manufacturer	Serial number	Name	Latest status	Record insertion time
2267	HGC Six Inch Silicon Module	SiDet	None	UCSB_HGC_TST_MOD_8		None	Dec. 11, 2017, 8:45 p.m.

Children							
ID	KindOfPart	Location	Manufacturer	Serial number	Name	Latest status	Record insertion time
2780	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-1		None	March 25, 2018, 10:20 p.m.
2781	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-2		None	March 25, 2018, 10:20 p.m.
2782	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-3		None	March 25, 2018, 10:20 p.m.
2783	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-4		None	March 25, 2018, 10:20 p.m.
2784	HPK Six Inch 128 Sensor Cell	Fermilab	Hamamatsu-HPK	HPK_6in_128_0003-5		None	March 25, 2018, 10:20 p.m.

wafer

inherits

Si Sensor

PARENT

(types HD  
120um, LD  
200um, and LD  
300um)

**Sensor\_ID (etched  
on wafer)**

CHILDREN

**Sensor\_ID or  
Scratchpad\_ID**

Example: 300um LD  
Si Sensor wafer

PARENT

Type 300um

**Sensor\_ID**

**Serial number: (wafer  
ID) N4791\_20. Or  
starting with HPK\_\*\_  
N4791\_20.**

**CHILDREN:**

**HPK\_\*\_N4791\_20-Full**


**HPK\_\*\_N4791\_20-PQC-TL**

**HPK\_\*\_N4791\_20-PQC-BR**

If it has an LD Full  
sensor, the only  
other children it  
can have are 2  
PQCs.

# User Tables

- User Tables has complicated Connections and components (hidden from user).
- xml template is used to define Upload our tables with dbloader.
  - How can we view what's in in2r/cmsr DBs?
  - Can XML template be used to transform the tables?
    - This might be needed, but would require collaboration from CERN, UCSB, etc. to reach consensus on what to store.
  - Is there a MM channel? If not, I created one: <https://mattermost.web.cern.ch/cms-exp/channels/cms-hgcal-db>
- In the future, we would like the uploading of test results to be automated.
- We would also like the results from the universal DB be very easy to query for everyone.



Thank you!

**Backup**

# Backup

$d_{act}$ ( $\mu\text{m}$ )	Full-size channels
120	432 (HD)
200	192 (LD)
300	192 (LD)

Parameter	LD	HD
Total sensor area	1 561 880 $\text{mm}^2$	1 561 880 $\text{mm}^2$
Size of full cell	118 $\text{mm}^2$	52 $\text{mm}^2$
No. of cells	198	444
No. of calibration cells	6	12
Inter-cell distance	50 $\mu\text{m}$	50 $\mu\text{m}$
<i>P</i> -stop width	6 $\mu\text{m}$	6 $\mu\text{m}$
Width of inner guard ring implant	131.5 $\mu\text{m}$	131.5 $\mu\text{m}$
Width of outer guard ring implant	18 $\mu\text{m}$	18 $\mu\text{m}$
Minimum width of edge ring implant	400 $\mu\text{m}$	400 $\mu\text{m}$
Distance guard rings	44.5 $\mu\text{m}$	44.5 $\mu\text{m}$
Distance guard ring to edge ring	209.5 $\mu\text{m}$	209.5 $\mu\text{m}$
Metal overhang cells	12.5 $\mu\text{m}$	12.5 $\mu\text{m}$
Inner metal overhang inner guard ring	12.5 $\mu\text{m}$	12.5 $\mu\text{m}$
Outer metal overhang inner guard ring	10 $\mu\text{m}$	10 $\mu\text{m}$
Inner metal overhang outer guard ring	10 $\mu\text{m}$	10 $\mu\text{m}$
Outer metal overhang outer guard ring	50 $\mu\text{m}$	50 $\mu\text{m}$
Inner metal overhang edge ring	50 $\mu\text{m}$	50 $\mu\text{m}$